




USER MANUAL – EN

IN 26641 Indoor Bike inSPORTline inCondi S150i



SevenSport s.r.o. reserves the right to make any changes and improvements to its product without prior notice. Visit our website www.insportline.eu where you will find the latest version of the manual.

CONTENTS

- DIAGRAM 4
- PARTS LIST 7
- ASSEMBLY 9
- CONSOLE 15
 - PROGRAMS 17
- USE 22
- CORRECT BODY POSTURE 22
- EXERCISE INSTRUCTIONS 22
- MAINTENANCE 23
- STORAGE 24
- IMPORTANT NOTICE 24
- ENVIRONMENT PROTECTION 24
- TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 24

SAFETY INSTRUCTIONS


- To ensure the best safety of the exerciser, regularly check it on damages and worn parts.
- If you pass on this exerciser to another person or if you allow another person to use it, make sure that that person is familiar with the content and instructions in these instructions.
- Only one person should use the exerciser at a time.
- Before the first use and regularly make sure that all screws, bolts and other joints are properly tightened and firmly seated.
- Before you start your work-out, remove all sharp-edged objects around the exerciser.
- Only use the exercise for your work-out if it works flawlessly.
- Any broken, worn or defective part must immediately be replaced and/or the exerciser must no longer be used until it has been properly maintained and repaired.
- Parents and other supervisory persons should be aware of their responsibility, due to situations which may arise for which the exerciser has not been designed and which may occur due to children's natural play instinct and interest in experimenting.
- If you do allow children to use this exerciser, be sure to take into consideration and assess their mental and physical condition and development, and above all their temperament. Children should use the exerciser only under adult supervision and be instructed on the correct and proper use of the exerciser. The exerciser is not a toy.
- Make sure there is sufficient free space around the exerciser when you set it up at least 0.6 m.
- To avoid possible accidents, do not allow children to approach the exerciser without supervision, since they may use it in a way for which it is not intended due to their natural play instinct and interest in experimenting.
- Please note that an improper and excessive work-out may be harmful to your health.
- Please note that levers and other adjustment mechanisms are not projecting into the area of movement during the work-out.
- When setting up the exerciser, please make sure that the exerciser is standing in a stable way and that any possible unevenness of the floor is evened out.
- Always wear appropriate clothing and shoes which are suitable for your work-out on the exerciser. The clothes must be designed in a way so that they will not get caught in any part of the exerciser during the work-out due to their form (for example, length). Be sure to wear appropriate shoes which are suitable for the work-out, firmly support the feet and which are provided with a non-slip sole.
- Be sure to consult a physician before you start any exercise program. He may give you proper hints and advice with respect to the individual intensity of stress for you as well as to your work-out and sensible eating habits.
- The indoor bike has no freewheel. The pedals will move if the flywheel is spinning.
- If you do not use the indoor bike, increase the resistance to the maximum to prevent the flywheel from moving.
- **Maximal weight limit:** 130 kg
- **Category:** HC for home use


IMPORTANT NOTES













- Assemble the exerciser as per assembly instructions and be sure to only use the structural parts provided with the exerciser and designed for it. Prior to the assembly, make sure the contents of the delivery are complete by referring to the parts list of the assembly and operating instructions.

- Be sure to set up the exerciser in a dry and even place and always protect it from humidity. If you wish to protect the place particularly against pressure points, contamination, etc., it is recommended to put a suitable, non-slip mat under the exerciser.
- The general rule is that exercisers and training devices are no toys. Therefore, they must only be used by properly informed or instructed persons.
- Stop your work-out immediately in case of dizziness, nausea, chest pain or any other physical symptoms. In case of doubt, consult your physician immediately.
- Children, disabled and handicapped persons should use the exercise only under supervision and in presence of another person who may give support and useful instructions.
- Be sure that your body parts and those of other persons are never close to any moving parts of the exerciser during its use.
- When adjusting the adjustable parts, make sure they are adjusted properly and note the marked, maximum adjusting position, for example of the saddle support, respectively.
- Do not work out immediately after meals!

DIAGRAM





	#22	1x
	#62 M10	1x
	#73 d10*Φ20*2	3x
	#13 M10*25*S8	2x
	#108 d10	2x
	#16 d8*Φ20*2	6x
	#15 d8	6x
	#14 M8*20*S6	6x
	#A S6	1x
	#C S8	1x
	#B S13-14-15	1x
	#D S13-15	1x


PARTS LIST

No.	Name	Qty.	No.	Name	Qty.
1	Console	1	36	Pedal L/R	1
2	Tablet holder	1	37	Hand knob M16	1
3	Bolt M5*35	2	38	Main frame	1
4	Grommet Φ 12.5	1	39	Bolt Φ 7.8*30*M6*15*S5	2
5	Left handle top cover	1	40	Bearing 608ZZ	4
6	Left handle bottom cover	1	41	Roller 71* Φ 19*24	2
7	Right handle top cover	1	42	Washer d6* Φ 12*1.5	2
8	Right handle bottom cover	1	43	Screw M6*12*S5	2
9	End ca	4	44	End cap J50*70	4
10	Computer Post	1	45	Front stabilizer	1
11	Wire 1	1	46	Nut M8	4
12	BoltM5*18* ϕ 8	12	47	Adjustable feet	4
13	BoltM10*25*S8	2	48	Rear stabilizer	1
14	BoltM8*20*S6	6	49	Screw ST3*12* ϕ 6	6
15	Spring Washer d8	6	50	Flywheel cover	2
16	Washer d8* ϕ 20*2	6	51	Nut M12*1	4
17	Handlebars	1	52	Wave pad d12* Φ 15.5*0.3	3
18	Handlebars frame	1	53	Spacer Φ 18* Φ 12.1*12.5	1
19	Wire 2	1	54	Bearing 6001Z	2
20	Handle M16*1.5	1	55	Weight bike	1
21	Seat	1	56	Flywheel axle	1
22	Cover	1	57	Bolt M5*10* Φ 9.5	13
23	Washer d6* ϕ 12*1	1	58	Front cover	1
24	Horizontal saddle holder	1	59	Cover	2
25	Seat lock	1	60	Bushing	4
26	Pin ϕ 3*20	1	61	Screw ST3*16* ϕ 5.6	8
27	M4*12 screw	2	62	Resistance knob	2
28	Limiter	1	63	Brake cover	1
29	Rubber pad ϕ 11* ϕ 8*3	1	64	Bushing	1
30	Sliding seat holder	1	65	Bolt Φ 10*285*M10*15*M6*7*M10*95	1
31	Cover	4	66	Nut M12*1*H6*S19	2
32	Sliding seat frame	2	67	Reinforcement plate	1
33	Rubber pad 2*29*19	2	68	Motor	1
34	Sliding seat frame plate	1	69	Cable 3	1
35	Seat post	1	70	Bolt M6*10	1

71	Nylon nut M10	1	96	Inner cover	1
72	Bolt M6*52	1	97	Screw ST4.2*8	1
73	Washer d10*φ20*2	4	98	Belt	1
74	Chain holder 30*10*1.5	1	99	Spring pad d6	4
75	Nylon nut M6*H6*S10	7	100	Magnet	1
76	Tension shaft	1	101	Belt plate	1
77	Tensioner pulley	1	102	Axis joint	1
78	Washer d6*Φ16*1.5	2	103	Bolt M6*16	4
79	Bolt M6*10	1	104	Outer cover	1
80	Washer d12	2	105	Ring	1
81	Magnetic plate axis	1	106	Sensor	1
82	Bolt M6*45	1	107	Heart rate cable	2
83	Magnet	4	108	Flexible washer d10	2
84	Brake pads 30*20*8	1	109	Horizontal Handlebar Tube	1
85	Magnetic plate	1	110	Fixed Plate of Horizontal Handlebar Tube	1
86	Tension spring	1	111	Brake bracket	1
87	Handle cover Φ25*7	2	112	Bolt M6*8*S3	1
88	Nut M10	2	113	Spring washerΦ1.2*Φ12*35*N10	1
89	L/P crank	1	114	Power cable	1
90	Cover	1	115	Tension cable	1
91	Pad d20	1	116	Adapter	1
92	Bearings	2	A	Wrench S6	1
93	Spacer	1	B	Spanner S13-14-15	1
94	Wave washer d20*Φ26*0.3	1	C	Wrench S8	1
95	Screw ST4.2*16	16	D	Spanner S13-S15	1


ASSEMBLY

Step 1



Use bolts (14), washers (15 and 16) to attach front stabilizer (45) and rear stabilizer (48) to main frame (38).

Step 2




Unscrew the hand knob (37) from the main frame (38) and slide the seat frame (35) into the main frame (38). Secure the seat frame (35) to the main frame (38) with the hand knob (37). The seat frame and main frame holes must be aligned.

Attach the saddle (21) to the horizontal saddle holder (30).

Connect the cables leading from the main frame (69) to the cable leading from the console bracket (19).

Pull the handle (20) out of the main frame (38) and slide the handle frame (18) into the main frame (38). Set the desired height, the holes of the main frame and the handle holder must be aligned.


Step 3



Connect the cables (11 and 19).

Slide the cables into the console frame (10) and then slide the console frame (10) into the handle frame (18) and secure with bolts (14) and washers (15 and 16).


Step 4



Attach horizontal handle plate (109) to handle holder (110) and secure to handle frame (18) with hand knob (62) and washer (73).

Attach handles (17) to handle plate (109) with bolts (13) and washers (108 and 73).

Step 5



Unscrew the bolts (3) from the back of the console (1).


Connect cables (106 a, b) and cable 1 (11) to console (1).

Attach the console (1) to the console holder (10) using the unscrewed bolts (3).


Attach the pedals (36 L/R) to the cranks (89 L/R) using the D wrench.

TRANSPORT

Grasp the trainer by the handles and tilt it onto the transport wheels on the front stabilizer (45).



RESISTANCE ADJUSTMENT




Use the hand knob (62) to change the resistance. Turn clockwise to increase, counterclockwise to decrease resistance.

LEVELING



Use the feet (47) to level the machine.

SEAT ADJUSTMENT




Use the hand knob (37) to adjust the height of the seat frame (35). Do not lift above the marked STOP sign.

Using the hand knob (24) you can adjust the distance of the saddle from the handles.


Re-tighten the hand knobs after any adjustment.

HANDLE ADJUSTMENT





Loosen the hand knob (20) and adjust the height of the frame (18). Do not exceed the marked height.

CONSOLE



Name	Function	Range
TIME	Exercise time	0M:00S ~ 99M:00S
SPEED	Exercise speed	0.0 ~ 99.9 km/h (mil/h)
DISTANCE	Distance	0.00 ~ 99.99 km (mil)


AVERAGE SPEED	Average speed	0.0 ~ 99.9 km/h (mil/h)
CALORIES	Burned calories	0 ~ 999 kcal
PULSE	Pulse	40 - 240 BPM
RPM	Revolutions per minute	0 ~ 999 RPM
WATT	Power	0 ~ 899 W
GEAR	24 levels of resistance	
FRONT	Front gear	1-3
REAR	Rear gear	1-8
	Front gear load adjustment (left handle)	
	Rear gear load adjustment (right hand grip)	

FUNCTIONS


MANUAL	Manual program. Resistance set manually.
PROGRAM	P1 / P2 / P3 / P4 / P5 / P6
BODY FAT	Body fat test
HRC	Heart rate program
USER PROGRAM	U1 / U2 / U3 / U4: user programs
Bluetooth&App	OPTIONAL – application support via Bluetooth
Chest strap	OPTIONAL - supports 5.3 kHz chest strap






BUTTONS


Keyboard



Touch



	Navigation button up, increase resistance
	Navigation button down, decrease resistance
	Return into the manual program (except programs U1-U4, FAT, HRC). Data reset
	Heart rate recovery test
	Confirms the value during setup


	Starts and stops the program
---	------------------------------


UNITS


Height	Weight	Pulse	Calories	Distance	Speet	RPM	WATT
Cm (Ft 'In)	Kg (lbs)	Beats per minute	Kcal	Km/Mil	Km/H Mil/H	Revolutions per minute	W




PROGRAMS



MANUAL




Press  to turn on program.

Press  for selecting and setting values / countdown (time, distance, calories, age).



Press   to adjust value and confirm by pressing  and move to the next value.



During the exercise, the resistance will be set according to the given program, or you can adjust the resistance using the buttons  .



If you set the program countdown, the value countdown is displayed. You will hear a beep when the count reaches 0.

You will stop the program by pressing .




PRESET PROGRAMS






Press buttons   to select program P1 – P6

Press  to start program, or press  to enter settings.


In the settings, you can set (time, distance, calories, age) for programs P1 – P5. For the P6 program you can set (time, distance).

Press   to adjust value and confirm by pressing  and move to the next value.


After setting all values, the program starts, or press  to start the program.

During the exercise, the resistance will be set according to the given program, or you can adjust the resistance using the buttons  .



If you set the program countdown, the value countdown is displayed. You will hear a beep when the count reaches 0.


You will stop the program by pressing .

BODY FAT



Press  to enter settings.

Press   to set values: gender (M-male, F - female) → height → age .

Press  to start an 8 second countdown. BMI, FAT% and BMR will be displayed.

The test should be performed in a resting state.

BMI (body mass index)

Gender/age	Malnutrition	Normal	Slightly overweight	Overweight	Obesity
Male ≤ 30	< 14	14 ~ 20	20.1 ~ 25	25.1 ~ 35	> 35
Male > 30	< 17	17 ~ 23	23.1 ~ 28	28.1 ~ 38	> 38
Female ≤ 30	< 17	17 ~ 24	24.1 ~ 30	30.1 ~ 40	> 40
Female > 30	< 20	20 ~ 27	27.1 ~ 33	33.1 ~ 43	> 43

FAT%

Gender	Low	Medium	Medium/high	High
Male	< 14%	13% - 25.9%	26% - 30%	> 30%
Female	< 14%	23% - 35.9%	36% - 40%	> 40%


BMR


Metabolism indicates the consumption of calories during the day.

Reference value: 1300 ± 100 (for age 22-40 years).


The values are indicative only and do not serve for medical purposes.



HRC




Press  to enter the settings. Set the data: time → distance → calories → target heart rate.

Press   to set values.

Press  to start program.


During the exercise, the resistance will be set according to the given program, or you can adjust the resistance using the buttons  .



If you set the program countdown, the value countdown is displayed. You will hear a beep when the count reaches 0.

You will stop the program by pressing .


It is necessary to detect the heart rate, otherwise the load will not be regulated to the target value.

USER PROGRAM



Press   to select U1 – U4.





Press  to start program, or press



ENTER

to enter settings. In the settings, you can set the values: time → distance → calories → resistance.



Press   to adjust value and confirm by pressing






ENTER

and move to the next value.



ST./SP.


After setting all values, the program starts, or press  to start the program.

During the exercise, the resistance will be set according to the given program, or you can adjust the resistance using the buttons  .


If you set the program countdown, the value countdown is displayed. You will hear a beep when the count reaches 0.



ST./SP.

You will stop the program by pressing .

RECOVERY



If heart rate is detected, press  / .

A 60 second countdown will start. Once it reaches 0, the result F1 (best) - F6 (worst) will be displayed.

The values are indicative only and do not serve for medical purposes.

Bluetooth

Using the FitShow application, you can connect the trainer to a smart device.

USE

Exercise on the indoor bike is based on very simple movements, but you will surely fall in love with them. Thanks to simplicity of the exercise on the indoor bike it can be done by elderly people. Prior to exercise, it is necessary to adjust the height of the saddle. It is important that you sit comfortably. The bicycle saddle must be set so that you can hold the ergonomically shaped handles when sitting. You should not have fully extended hands. You can damage your muscles.

To ensure a comfortable and comfortable exercise, put your feet on the pedal. Nowadays, all modern pedals are equipped with straps for fastening and stabilizing of the foot. It is important for your foot to be firmly and safely positioned during exercise.

The basis of exercising on a bicycle is that the legs are moving on a specific elliptical path. This movement is very similar to cycling. When doing exercise on a bicycle, you just sit on the saddle with the right height, keep your feet firmly in the pedals, hold the ergonomically shaped handles and exercise.

It is advisable at the beginning to choose a lower load. If you exercise at regular intervals on an indoor bike, you can gradually increase the load. You can increase the load gradually over a week or two weeks. Selecting a high load during the start of training can lead to rapid fatigue and muscle damage.

When exercising, it's important to choose the right load and the right tempo. Try to keep it throughout the exercise. It is not recommended to choose a high pace right from the start. Increase tempo after about a week of regular exercise. The high pace is not equal to the faster burning of calories. Correct calorie burning is reflected in an appropriate and regular exercise. At the beginning of the exercise, the number of burned calories may seem low, but regular and appropriate exercise is the key to achieving the best results.

Exercise on the indoor bike also leads to the formation of muscles. It is mainly used to strengthen the thigh and calf muscles. While exercising on a bicycle, you also move your buttocks.

If you want to exercise right, you should not forget to breathe properly. Proper and regular breathing is recommended in any exercise. It is important to keep regular deep inhales and exhales. Regular and proper breathing during exercises on the indoor bike involves intense exercise of the abdominal muscles. It is advisable to practice 30-35 after consuming food. Failure to do so may result in less calories burned, and in older age even lead to digestive problems.

For best results, you should also consider your diet. It is recommended to start a day of eating sweet food and pastries or muesli with milk. For lunch is recommended to eat a caloric richer meal. Do not forget about the soup. In the evening, light meals are recommended. If you want to improve your health, it's not just a regular exercise but a whole diet.

Bicycle exercise is an effective exercise for all busy people. Exercise on the indoor bike is effective in strengthening muscles, especially thighs, calves and buttocks. Regular exercise can lead to a slimmer figure. Exercise is recommended not only as a winter training for cyclists but also for people who want to burn excess calories. Regular breathing, regular exercise, reasonable tempo, and balanced diet can lead to your desired results.

CORRECT BODY POSTURE

When training, keep your body upright, or you can learn your hand on your forearms. During pedaling, you should not have your legs fully extended. Your knees should be slightly bent when fully pressing down the pedal. Keep your head straight with your spine to minimize the pain of the cervical muscles and upper back muscles. Always exercise fluently and rhythmically.

EXERCISE INSTRUCTIONS

A successful workout begins with warm-up exercises and ends with cool-down (relaxing) exercises. The warm-up exercises should make your body ready for the main workout. The cool-down phase should protect your muscles from injuries and cramps. Do warm-up and cool-down exercises as shown in the chart below.



Touching your toes

Slowly bend your back from hips. Keep your back and arms relaxed while stretching downwards to your toes. Do it as far as you are able and hold the position for 15 seconds. Bend your knees slightly



Upper thigh

Lean against a wall with one hand. Reach down and behind you. Lift up your right or left foot to your buttock as high as possible. Keep for 30 seconds and repeat twice for each leg.



Hamstring stretched

Sit and outstretch your right leg. Rest the sole of your left foot against the inside of your right thigh. Stretch out your right arm along your right leg as far as you can. Hold for 15 seconds and relax. Repeat all with your left leg and left arm



Inside upper thigh


Sit on the floor and place your feet together. Knees are pointed outwards. Pull your feet as close as possible to your groin. Press your knees carefully downwards. Keep this position for 30-40 seconds if possible.



Calves and Achilles tendon

Lean against a wall with your left leg in front of the right one and your arms forward. Stretch out your right leg and keep your left foot on the floor. Bend your left leg and lean forwards by moving your right hip in the direction of the wall. Hold for 15 seconds. Keep your leg stretched and repeat exercising with other leg.

Exercise Stage. Regular exercise will make your muscles stronger. Keep the pace according to the chart during the training. Training should take at least 12 minutes.



Then let the muscles calm down by reducing the pace for approx. 5 min. Then do the warm-up exercises. Train regularly at least 3 times a week.

MAINTENANCE

- When assembling, tighten all screws and adjust the bike to the horizontal position.
- Check the screws after 10 hours of use.

- Wipe the sweat after the exercise. Clean the device with a cloth and gentle cleanser. Do not use solvents or aggressive cleaners on the plastic parts.
- When noise is increased, it is necessary to check that all joints are tightened properly.
- Place the product in a clean, ventilated and dry room.
- Do not expose the device to direct sunlight.

STORAGE

Keep the indoor bike in a clean and dry environment. Make sure that the indoor bike is not plugged in to the socket.

IMPORTANT NOTICE

- This indoor bike comes with standard safety regulations. Any other use is prohibited and may be dangerous to users. We are not responsible for any injury caused by improper and forbidden use of the machine.
- Consult your doctor before starting training on the indoor bike. Your doctor should evaluate whether you are physically fit to use the machine and how much effort you are able to undergo. Incorrect exercise or switching of the body can harm your health.
- Carefully read the following tips and exercises. If you experience pain, nausea, breathing, or other health problems during exercise, immediately stop the exercise. If the pain persists, contact your doctor immediately.
- This indoor bike is not suitable for medical purpose. It can also not be used for healing purposes.
- The heart rate monitor is not a medical device. It provides only approximate information about your average heart rate, and any suggested pulse rate is not medically binding. Accumulated data may not always be accurate regarding uncontrollable human and environmental factors.

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyards.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

Batteries

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZ
SEVEN SPORT s.r.o.

Registered Office: Strakonická 1151/2c, Praha 5, 150 00,
ČR

Headquarters: Dělnická 957, Vítkov, 749 01

Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264

VAT ID: CZ26847264

Phone: +420 556 300 970

E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK
inSPORTline s.r.o.

Headquarters, warranty & service center: Električná 6471,
Trenčín 911 01, SK

CRN: 36311723

VAT ID: SK2020177082

Phone: +421(0)326 526 701

E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk

Web: www.inSPORTline.sk

About shipping

